


DISABLED REFUGE SYSTEM

OPERATING INSTRUCTIONS

IN CASE OF EMERGENCY



Flashing red LED & handset ringing = incoming call

To Answer a Call

Lift handset.

You will automatically be connected to the caller.

To finish a call, replace the handset.

The red LED stays on to show that someone is at that location.

To Speak to a Previous Caller

Lift the handset and press the area button.

You will be connected to the caller.

To Speak to All Previous Callers

Press the 'ALL' button and speak into the handset.

When Emergency is Over

Replace handset, then press and hold each Area Button in turn until the red Call Indicator goes out.

