

TECHNICAL BULLETIN

BBTB Date: 10 September 2021

BBTB Number: BBTB-065

BBTB Title: BVOCRIF / DTAKIT - DTARP does not in-

itially illuminate or sound buzzer

System Description: OmniCare Systems using BVOCRIF and

DTAKIT

Product(s) Affected: BVOCRIF

Reference: PRCR2371

Priority: 3

I - Essential: Action is Recommended

2 - Important: Product Form / Fit / Function has been changed (may affect compatibility)

3 - General: For information / reference

4 - Obsolescence: Notification of Component or Product Obsolescence

DESCRIPTION OF THE PROBLEM

Baldwin Boxall has become aware of an issue with a small quantity of BVOCRIF modules that may affect the operation of the DTAKIT interface. A component tolerance issue has been identified that may affect the initial operation of the DTAKIT when the pullcord is first triggered.

SYMPTOMS OF THE PROBLEM

When first triggered, the DTARP does not immediately illuminate the LED or sound the buzzer, however on the second pull (or if the cord is initially pulled for 1s or longer) the DTARP illuminates & sounds the buzzer.

Please note that on the first pull the call is still correctly received by the Control Panel, and the DTODL illuminates & sounds the sounder.

SUGGESTED ACTION

Baldwin Boxall will replace BVOCRIF modules with this issue. Please contact us to arrange for Advance Replacement units to be supplied free of charge.



TECHNICAL BULLETIN

Customer Services Contact Details

For further assistance with any aspect of this Technical Bulletin please contact:

Baldwin Boxall Communications Ltd

Robbie Trent (Service Manager) Email: robbie@baldwinboxall.co.uk

Ashley Wright (Customer Support Engineer)

Email: ashley@baldwinboxall.co.uk

Steve Bladon (Operations Manager) Email: steveb@baldwinboxall.co.uk

Telephone: +44 (0) 1892 664422 Facsimile: +44 (0) 1892 663146